

Belltes Academy

Signal Processing & Embedded Systems

written by Belltes Khoza

Section A: The 10 Core Topics Overview

1. Sampling & The Nyquist-Shannon Theorem

Summary: The mathematical bridge that allows continuous real-world analog signals (like sound) to be converted into discrete digital numbers without losing information.

Engineering Example: Setting the audio sampling rate of a high-fidelity studio microphone to 44.1 kHz to perfectly capture human hearing limits up to 20 kHz.

Analogy: Flipbook Animation. If you draw a cartoon running across the pages, you must draw a minimum number of frames per second. If you draw too few frames, the motion looks choppy, broken, and unreadable.

2. Discrete Fourier Transform (DFT) & FFT

Summary: An algorithm that converts digital signals from the time domain (how it changes over time) into the frequency domain (what notes or pitches make it up).

Engineering Example: Programming a Fast Fourier Transform (FFT) into a smartphone mic app to show a real-time audio spectrum analyzer visual.

Analogy: Deconstructing a Smoothie. If you drink a mixed fruit smoothie, the time domain is the single blended taste. The Fourier Transform acts like a machine that separates the smoothie back into piles of strawberries, bananas, and blueberries.

3. Digital Filter Design (FIR & IIR)

Summary: Mathematical algorithms implemented in software or hardware to remove unwanted noise, smooth out data, or isolate specific signal bands.

Engineering Example: Designing a Finite Impulse Response (FIR) low-pass filter to clean up raw electrical noise coming from an ECG heart monitor patch.

Analogy: A Water Purifier Filter. Raw river water contains sand, mud, and chemicals. Passing it through a physical charcoal filter leaves you with perfectly clean, pure drinking water.

4. Microcontroller Architecture & Peripherals

Summary: The structural blueprint of a single-chip computer, including its CPU core, memory blocks, and built-in hardware engines like timers and communication modules.

Engineering Example: Utilizing an ARM Cortex-M microcontroller to coordinate data pipelines between an on-board temperature sensor and a flash memory chip.

Analogy: An Office Workstation. The CPU is the worker at the desk. RAM is the desktop space where paperwork is actively held, and built-in peripherals are the office phone, printer, and calculator right next to them.

5. Embedded C & Memory Management

Summary: The specialized programming techniques used to write highly optimized, deterministic software code that interacts directly with low-level hardware registers and limited memory.

Engineering Example: Writing low-level driver code in Embedded C to map sensor register bits directly into a microscopic microcontroller RAM partition.

Analogy: Packing a Backpack for a Hike. You have a strictly limited volume of space. You cannot pack heavy luxury items; you must optimize every square centimeter with exact, highly essential tools.

6. Analog-to-Digital (ADC) & Digital-to-Analog (DAC) Conversion

Summary: The hardware interfaces that translate physical voltages into digital binary bits (ADC) and recreate physical voltages back from digital code (DAC).

Engineering Example: Connecting an automotive pressure sensor to a 12-bit ADC pin to monitor engine oil levels safely on a vehicle computer.

Analogy: A Translator and a Dictator. The ADC listens to spoken words (analog) and writes them down as text codes (digital). The DAC reads text codes (digital) and speaks them out loud over a loudspeaker (analog).

7. Real-Time Operating Systems (RTOS)

Summary: A specialized operating system designed to run multiple embedded software tasks concurrently with strict, guaranteed timing deadlines.

Engineering Example: Deploying FreeRTOS inside a car's engine control unit (ECU) to guarantee that an airbag deployment task overrides all other system actions instantly during a crash.

Analogy: An Air Traffic Controller. They don't just guide planes whenever they feel like it; they manage multiple arriving flights simultaneously, giving absolute emergency landing priority to a plane running out of fuel.

8. Hardware Communication Protocols (I2C, SPI, UART)

Summary: The standard electronic digital rules and wire buses used to exchange data between integrated chips on a circuit board or across devices.

Engineering Example: Using a 2-wire I2C bus to link a digital gyroscope sensor straight to a drone's main flight control microprocessor.

Analogy: Intercom Systems vs. Walkie-Talkies. UART is like a direct phone call between two specific people. I2C is like a shared office intercom where you shout a specific name before delivering a message down the hall.

9. Convolution & System Impulse Response

Summary: The core mathematical operation that predicts what a digital system's output will look like by blending an input signal with the system's unique 'signature' response.

Engineering Example: Simulating how an audio track will sound inside a grand concert cathedral by convolving the dry audio file with the room's recorded acoustic echo signature.

Analogy: Stamping a Logo on Paper. The input signal is the plain paper. The system impulse response is the physical rubber ink stamp. When you stamp the paper (convolution), the final output holds the exact impression of the stamp shape.

10. Low-Power Optimization & Watchdog Timers

Summary: Hardware and software strategies designed to minimize battery drain while using safety timers to auto-reset the system if the code freezes.

Engineering Example: Putting a smart utility water meter into a Deep Sleep state for 23 hours a day, waking up briefly via a hardware timer to beam data.

Analogy: A Smart Security Guard with a Dead-Man's Switch. The guard sleeps to conserve energy, waking up briefly to check the facility. They must press a safety button every 60 seconds (Watchdog kick); if they pass out and fail to press it, an emergency alarm instantly resets the building.

Section B: The 100 Key Terms & Glossary

Topic 1: Sampling & The Nyquist-Shannon Theorem

1. Sampling Frequency (f_s)

Definition: The number of discrete signal measurements or snapshots taken per second to convert a continuous analog signal into digital data, measured in Hertz (Hz).

Example: Recording voice data at a sampling rate of 8,000 Hz for standard digital telephone network lines.

Analogy: Strobe lights at a dance club. If the light flashes rapidly, you can track the dancer's exact movements; flash it once every ten seconds, and they seem to teleport.

2. Nyquist Rate

Definition: The minimum theoretical sampling frequency required to perfectly reconstruct a bandlimited signal, equal to exactly twice the highest frequency component present in the signal.

Example: For an audio signal containing frequencies up to 22 kHz, the Nyquist rate dictates a sample clock of at least 44 kHz.

3. Aliasing

Definition: A destructive distortion phenomenon where high-frequency signal components are falsely mapped as lower frequencies due to an inadequate sampling rate.

Example: A 30 kHz radio noise signal appearing as a fake 10 kHz signal inside an under-sampled 40 kHz ADC processing loop.

Analogy: The wagon-wheel effect in movies. If a camera captures too few frames per second, a fast-spinning car tire looks like it is spinning backward slowly.

4. Anti-Aliasing Filter

Definition: An analog low-pass filter circuit placed strictly before an ADC input to attenuate all signal frequencies higher than half the sampling rate.

Example: A hardware active filter cleaning an industrial vibration sensor line before the digital microcontroller samples the data pins.

Analogy: A height-limit bar at a parking garage entrance that physically blocks tall trucks from getting stuck inside the low-clearance lot.

5. Quantization

Definition: The process of mapping a continuous range of analog voltage values into a finite set of discrete, step-like digital binary code levels.

Example: Rounding a precise sensor reading of 3.4276 Volts to exactly 3.43 Volts on a digital controller display screen.

Analogy: Lining up people by height. Instead of measuring someone as exactly 174.32 cm, you round them into the '170-175 cm' bracket category.

6. Quantization Noise

Definition: The inherent rounding error or discrepancy introduced during quantization, manifesting as a random background hiss or noise floor in digital signals.

Example: The faint background noise floor heard when a high-end 24-bit audio file is down-sampled into a lower 8-bit format.

7. Dynamic Range

Definition: The ratio between the largest treatable signal amplitude and the smallest detectable signal amplitude within a digital signal processing system, measured in decibels (dB).

8. Signal-to-Quantization-Noise Ratio (SQNR)

Definition: A metric that quantifies the signal quality of an ADC system, scaling upward by roughly 6 dB for every single extra bit of resolution added.

9. Jitter

Definition: The undesirable short-term variations or instabilities in the clock timing edges of a digital sampling circuit, causing signal distortion.

Example: A shaky crystal oscillator causing an audio codec chip to sample at uneven intervals, adding phase distortion to the sound.

Analogy: A drummer who loses their rhythm slightly, hitting the snare drum a fraction of a millisecond too early or too late on every beat.

10. Oversampling

Definition: The technique of sampling an analog signal at a frequency significantly higher than the bare minimum Nyquist rate to spread out quantization noise.

Topic 2: Discrete Fourier Transform (DFT) & FFT

11. Discrete Fourier Transform (DFT)

Definition: A mathematical algorithm that takes a finite sequence of discrete time-domain samples and computes their corresponding frequency-domain spectrum.

Example: Calculating the specific active frequency mix inside an industrial motor vibration sample block.

12. Fast Fourier Transform (FFT)

Definition: A highly optimized, computationally efficient algorithm used to calculate the DFT by reducing the complexity from $O(N^2)$ down to $O(N \log N)$.

Example: Running a real-time signal analysis loop on a digital radar processor to track aircraft velocity steps instantly.

Analogy: A math shortcut. Instead of multiplying a long list of numbers row-by-row, you group them into patterns to finish the math work in seconds.

13. Frequency Bin

Definition: A single discrete frequency point or narrow data division interval in the output spectrum grid of a DFT computation.

Example: An FFT output where Bin #4 represents the precise signal power gathered between 50 Hz and 60 Hz.

Analogy: A row of sorting boxes at a post office, where mail is tossed into specific slots based on the target zip code zone.

14. Spectral Leakage

Definition: A signal processing distortion where energy from a specific frequency 'leaks' out into neighboring bins because the sampled signal waveform was cut off mid-cycle.

Example: A clean 100 Hz sine wave appearing as a smeared, wide hill on an FFT chart instead of a sharp needle spike.

15. Windowing

Definition: The process of multiplying a time-domain data block by a specialized tapering function (like a Hann or Hamming window) to eliminate edge discontinuities.

Example: Applying a Blackman window to an industrial acoustic stream sample before calculating an FFT to suppress side-lobe artifacts.

Analogy: Fade-in and fade-out video transitions. It smooths out harsh, abrupt video scene changes so the viewer doesn't experience a sudden visual shock.

16. Time Domain

Definition: A perspective that analyzes a signal's amplitude variations with respect to real-world continuous chronological time milestones.

Example: Viewing a live heartbeat trace pulsing up and down on a hospital bedside monitoring screen grid.

17. Frequency Domain

Definition: A perspective that analyzes a signal grouped by its constituent frequencies, showing the magnitude and phase of each frequency band.

18. Resolution (Spectral)

Definition: The capability of an FFT operation to separate and distinguish between two individual frequency components that sit closely packed together.

19. Picket Fence Effect

Definition: The phenomenon where the true peak amplitude of a signal is missed or underestimated because it falls directly between two discrete FFT bin points.

Example: A sharp 55.5 Hz signal power tracking slightly lower on a chart because the closest measurement bins sit at exactly 55 Hz and 56 Hz.

Analogy: Peeking at a mountain landscape through a vertical wood picket fence; parts of the scenery are hidden behind the solid wood slats.

20. Phase Spectrum

Definition: The plot or dataset showing the precise alignment angular phase shifts of each frequency component present in a computed signal spectrum.

Topic 3: Digital Filter Design (FIR & IIR)

21. Finite Impulse Response (FIR) Filter

Definition: A non-recursive digital filter whose output depends strictly on current and past input samples, making its response duration inherently finite and inherently stable.

Example: Implementing a linear-phase low-pass FIR filter inside an advanced audio studio mixer board plugin.

Analogy: Calculating a simple moving average. To find your average score, you only add up your last 5 test marks; old past history completely drops off the sheet.

22. Infinite Impulse Response (IIR) Filter

Definition: A recursive digital filter whose output relies on both past input samples and past output feedback loop cycles, allowing an infinitely long response duration.

Example: Recreating a classic analog Butterworth low-pass filter stage in digital software code using minimal CPU memory steps.

Analogy: An echo chamber. You shout into a cavern; the sound loops back into the microphone, creating an endless trail of quieter and quieter echoes that repeat forever.

23. Filter Coefficients

Definition: The fixed scalar multipliers used within a digital filter's difference equation to scale input and output values to alter the frequency response.

Example: Storing an array of 64 floating-point constant numbers in flash memory to define a precise 50 Hz notch filter structure.

Analogy: Tuning sliders on a baking recipe card; they dictate exactly how many cups of flour or sugar to mix in to change the final cake texture.

24. Linear Phase

Definition: A property of a filter where the phase delay is directly proportional to frequency, ensuring that all signal components are delayed by the exact same amount of time.

Example: Utilizing an FIR filter on a high-speed data modem line to prevent digital binary pulses from smearing into each other.

25. Passband

Definition: The specific frequency range or channel band that a filter allows to pass through from input to output with minimal scale reduction or loss.

26. Stopband

Definition: The specific frequency range that a filter aggressively suppresses, blocks, or attenuates below a specified threshold level.

27. Transition Band

Definition: The narrow frequency region that sits between the edge of a filter's passband and the start of its stopband, characterizing the steepness of the filter roll-off.

28. Order of a Filter

Definition: The number of internal delay elements or memory storage taps used within a digital filter structure, defining its performance steepness.

Example: Upgrading from a 2nd-order IIR filter to an 8th-order alternative to achieve a razor-sharp cut-off curve on a radar line.

29. Bilinear Transformation

Definition: A mathematical mapping technique used to convert an analog continuous s-domain filter design into a discrete digital z-domain equivalent filter.

30. Group Delay

Definition: The rate of change of total phase shift with respect to frequency, tracking the real time delay experienced by a packet of signal frequencies passing through a filter.

Topic 4: Microcontroller Architecture & Peripherals

31. Harvard Architecture

Definition: A computer architecture design that utilizes physically separate memory storage pathways and signal buses for code instructions and data variables.

Example: An AVR or ARM Cortex-M microcontroller fetching an instruction from flash memory while simultaneously reading a data variable from RAM.

Analogy: A modern house with a dedicated front entryway door for guests and a separate back garage door for loading groceries. Both can open at the exact same time.

32. Von Neumann Architecture

Definition: A computer architecture where both software program instructions and data variables share the exact same physical memory space and system data bus.

33. General Purpose Input/Output (GPIO)

Definition: Pin connections on a microcontroller that can be dynamically programmed via software code to act as digital inputs (reading switches) or digital outputs (driving LEDs).

Example: Setting Microcontroller Pin PC13 to output mode to toggle an onboard status indicator light.

Analogy: A universal electrical socket wall toggle that you can either plug a reading lamp into (output) or connect an ambient light sensor up to (input).

34. Interrupt Service Routine (ISR)

Definition: A dedicated, high-priority software function block that executes immediately when a specific hardware event or interrupt trigger occurs, pausing the main code.

Example: A safety ISR function running instantly to cut motor power when a hardware limit-switch pin is physically bumped on a CNC machine.

Analogy: An emergency phone ring. You are busy reading a novel, but if the smoke alarm screeches, you drop the book instantly to deal with the fire.

35. Direct Memory Access (DMA)

Definition: A hardware engine peripheral that transfers data blocks directly between memory partitions or peripherals completely independent of the main CPU core.

Example: Streaming high-speed incoming ADC samples straight into a global RAM array buffer without waking up the main processor core on every byte step.

Analogy: Hiring a moving company. Instead of the company boss physically carrying boxes one by one, they hire external laborers to clear out the room while the boss keeps typing emails.

36. Watchdog Timer (WDT)

Definition: A specialized hardware countdown safety timer that forces a full hardware reset of the microcontroller if the main program code hangs or crashes.

37. Timers/Counters

Definition: Internal peripheral hardware blocks that count incoming clock cycles to generate precise time delays, measure frequencies, or trigger software tasks.

38. Pulse Width Modulation (PWM)

Definition: A technique for generating pseudo-analog voltage levels using a digital output pin by rapidly toggling it high and low, varying the 'on' time duty cycle.

Example: Dimming a dashboard light cluster panel smoothly from 0% to 100% using a 1 kHz microcontroller timer output signal.

Analogy: Flickering a bedroom light switch on and off 100 times a second. If it stays on for 90% of the time, your eyes perceive a bright room; if only on for 10%, the room feels dim.

39. Register

Definition: A microscopic, ultra-fast memory storage cell located directly inside the CPU core or peripheral block used to configure settings or read real-time pin states.

40. Clock Tree

Definition: The internal distribution network of oscillators, prescalers, and multipliers that routes precise timing clock frequencies to various peripheral subsystems.

Topic 5: Embedded C & Memory Management

41. Volatile Keyword

Definition: A compiler directive in C that prevents the optimization engine from caching a variable, forcing the CPU to reread its value from memory every single time it is called.

Example: Defining volatile uint8_t flag; for a variable whose value is updated inside a hardware interrupt handler function.

Analogy: A live stock market ticker screen. You cannot assume the price of oil matches what you read 5 minutes ago; you must look at the active screen layout every time.

42. Static Keyword (Local)

Definition: A C variable modifier that forces a local variable to preserve its stored value in memory even after the function block it was created in finishes executing.

Example: Keeping track of total sensor error counts inside a cyclic algorithm function using a local static variable counter loop.

43. Flash Memory

Definition: Non-volatile, permanent memory space used inside an embedded system to store the compiled binary machine code instructions.

Example: Flashing a new firmware update image down onto the non-volatile memory block of a smart home thermostat.

Analogy: A printed textbook. The text is written permanently; turning off the room lights (removing power) doesn't wipe the ink off the page layers.

44. SRAM (Static RAM)

Definition: Volatile memory space used to store runtime variable values, stacks, and heap data, losing all content the moment power is cut.

Example: Allocating global temporary calculation array blocks inside a microcontroller's fast internal volatile scratchpad memory space.

Analogy: A whiteboard in a meeting room. You write notes freely during the session, but at the end of the day, someone wipes it fully blank for tomorrow.

45. Stack

Definition: A Last-In, First-Out (LIFO) memory region managed automatically by the CPU to hold local function variables, return addresses, and processor status values.

Example: Storing local variables and tracking where to return in code when a main function jumps down to execute a calculation sub-routine block.

Analogy: A stack of kitchen plates. You pile plates up one on top of the other. The last plate you place down on the stack is the absolute first one you must lift off later.

46. Heap

Definition: A dynamic memory region allocated manually by the programmer at runtime using memory management commands, prone to fragmentation in embedded systems.

47. Bit Masking

Definition: A bitwise programming technique using operators (AND, OR, XOR) to isolate, clear, or set specific individual bits within a single configuration register byte.

Example: Turning on bit position 3 of a configuration register byte using the C command line operation: `REG |= (1 << 3);`.

Analogy: A stencil plate placed over a sheet of wood. Spraying paint only colors the exact cutout holes exposed by the stencil, leaving the rest untouched.

48. Pointer

Definition: A C variable that stores the physical memory address location of another variable or peripheral register rather than holding data directly.

49. Memory-Mapped I/O

Definition: A hardware design approach where peripheral control registers are assigned specific addresses within the main memory map layout.

50. Stack Overflow

Definition: A fatal software runtime error that occurs when the stack memory region exceeds its allocated boundary, crashing down into RAM space.

Topic 6: Analog-to-Digital (ADC) & Digital-to-Analog (DAC) Conversion

51. ADC Resolution

Definition: The total number of discrete digital output levels an ADC can produce over a full voltage scale range, typically expressed as a count of bits.

Example: A 10-bit ADC breaking down a 0-5V sensor scale into exactly 1,024 individual digital measurement steps.

Analogy: A ruler grid. A cheap ruler only has markings for centimeters (low resolution); an engineer's ruler has markings down to tenths of a millimeter (high resolution).

52. Successive Approximation Register (SAR) ADC

Definition: An ADC architecture that determines a digital code value for an analog voltage by executing a binary-search algorithm through all bit levels one step at a time.

Example: A microchip's internal SAR hardware peripheral balancing a sensor voltage reading over 12 successive clock comparisons.

Analogy: An old balancing scale. To weigh an object, you place a large 1kg block; too heavy? Remove it and try a 500g block. Too light? Keep it and add a 250g weight, narrowing down step-by-step.

53. Flash ADC

Definition: A parallel ADC architecture that utilizes a large bank of voltage comparators to determine an analog value instantly at the cost of high power and silicon area.

54. Integral Non-Linearity (INL)

Definition: A metric tracking the maximum deviation between the actual non-ideal ADC transfer function curve and the perfect theoretical straight-line ideal conversion response.

55. Differential Non-Linearity (DNL)

Definition: The variation or deviation in step width between any two adjacent discrete digital code steps across an ADC or DAC transfer function sheet.

56. R-2R Ladder

Definition: A simple, high-performance DAC circuit architecture built using an repeating chain of resistors of values R and 2R to scale output voltages cleanly.

Example: Fabricating a cheap audio sound wave generator circuit using an array of discrete resistors hooked directly up to GPIO pins.

57. Settling Time (DAC)

Definition: The time delay required for a DAC's analog output voltage step to stabilize within a specified error margin after a new digital input code is clocked in.

58. Reference Voltage (Vref)

Definition: The highly stable constant baseline voltage used by an ADC or DAC to define the absolute maximum limit scale of the conversion grid.

Example: Using a precision 3.3V reference regulator chip to ensure an ADC can measure incoming battery states without reading fluctuating results.

Analogy: The sea level benchmark line on a global map. Every mountain height calculation relies entirely on that one fixed baseline mark staying constant.

59. Glitch Impulse Area

Definition: The undesirable transient voltage spike or ring artifact that appears at a DAC output during a major digital code transition point (like switching from 0111 to 1000).

60. Sample and Hold Circuit

Definition: An internal analog circuit stage that captures a transient voltage sample on a capacitor and locks its level steady while the ADC chip completes its math.

Topic 7: Real-Time Operating Systems (RTOS)

61. Task / Thread

Definition: An independent, concurrent software code loop executed under RTOS scheduler control, assigned its own unique priority level and stack space.

Example: Designing a smart appliance with one task running code to update an LCD screen and a second task watching communication pins.

Analogy: A chef preparing a meal. They have one active job tracking a pot boiling on the stove and a separate job cutting vegetables nearby.

62. Scheduler

Definition: The core engine algorithm inside an RTOS kernel that determines which ready software task should be loaded into the CPU core to execute at any given tick.

Example: A preemptive priority scheduler pausing a low-priority logging task to run an active motor control task.

63. Preemption

Definition: The operational act of an RTOS scheduler immediately suspending a currently running task to pass CPU control to a newly unblocked higher-priority task.

Example: Forcing a data logging loop to pause execution instantly when a critical low-battery power alarm task trips.

Analogy: A police car with sirens on. You are driving normally down a narrow road, but you must pull over sideways to stop and let the emergency vehicle speed past.

64. Semaphore

Definition: A synchronization token mechanism used to control access to a shared resource or signal task milestones across an RTOS code ecosystem.

Example: Utilizing a counting semaphore to manage exclusive access to a single debugging print port shared across five running tasks.

Analogy: A key card for a single-person office bathroom. If someone takes the key card from the hook, no one else can unlock the door until the key is hung back up.

65. Mutex (Mutual Exclusion)

Definition: A specialized binary semaphore variant that includes priority inheritance, used to securely lock a single asset to prevent priority inversion traps.

66. Priority Inversion

Definition: A dangerous software bug condition where a low-priority task holds a resource lock, blocking a high-priority task, while a medium-priority task runs freely.

Example: The famous Mars Pathfinder rover glitch, where a critical navigation loop hung up because a low-level telemetry task locked an internal system data bus.

67. Context Switch

Definition: The systematic operation performed by an RTOS kernel to save the active CPU register states of a running task and reload the states of a different task.

68. Determinism

Definition: The structural system characteristic where a software task execution duration and timing response is completely predictable, reproducible, and guaranteed.

Example: Engineering a robotic brake deployment system to fire safely within exactly 500 microseconds of an obstacle alert every single time.

Analogy: A Swiss railway train schedule. It doesn't arrive 'sometime around noon'; it pulls into the station platform precisely at 12:00:00 without fail.

69. Task Bloat / Starvation

Definition: A state where a lower-priority task never gets a chance to run because higher-priority loops consume 100% of the available CPU clock cycles.

70. Tick Rate

Definition: The periodic frequency rate (typically 1 kHz) at which a hardware timer interrupt alerts the RTOS kernel to update schedules and check task deadlines.

Topic 8: Hardware Communication Protocols (I2C, SPI, UART)

71. UART (Universal Asynchronous Receiver-Transmitter)

Definition: A simple 2-wire serial communication hardware protocol that transmits data bytes sequentially bit-by-bit without using a shared clock wire line.

Example: Connecting an old GPS module receiver line to an embedded microchip using simple TX and RX crossing wires.

Analogy: Two friends writing letters to each other. They don't need to read at the same speed; as long as they agree on formatting rules, the letter carries data.

72. I2C (Inter-Integrated Circuit)

Definition: A synchronous, multi-master, multi-slave 2-wire serial bus protocol utilizing a bidirectional Serial Data (SDA) line and a Serial Clock (SCL) line with pull-up resistors.

Example: Hooking up multiple digital barometric pressure sensors to a single microcontroller chip using just two shared I2C bus pins.

73. SPI (Serial Peripheral Interface)

Definition: A high-speed, full-duplex synchronous 4-wire serial communication protocol that utilizes dedicated Master-Out-Slave-In (MOSI) and Slave-Select lines.

Example: Streaming high-resolution raw camera image frames straight to an SD memory card slot using a 20 MHz SPI clock bus line.

Analogy: A drill sergeant barking direct orders down a headset. The soldiers listen and respond instantly at the exact rhythm dictated by the sergeant's voice ticks.

74. Baud Rate

Definition: The rate or speed at which data symbols or bits are transmitted across an asynchronous serial communication channel wire, measured in bits per second (bps).

Example: Setting both an embedded module and a PC serial terminal connection port config to exactly 115,200 baud to avoid corruption.

75. Full-Duplex

Definition: A communication link capability that allows data characters to be actively transmitted and received simultaneously in both directions along the same channel path.

Example: An SPI bus connection where data bytes fly out along the MOSI line while feedback bytes return along the MISO line on the exact same clock tick.

Analogy: A two-way phone conversation. Both people can speak out loud and listen to each other at the exact same moment down the wire line.

76. Half-Duplex

Definition: A communication link capability where data can move in both directions, but only in one single direction at a time; devices must alternate transmitting.

77. Start/Stop Bits

Definition: Frame bits appended to the beginning and end of a raw data byte package inside an asynchronous UART link to synchronize the receiver engine.

78. Pull-Up Resistor

Definition: Resistors connected between a communication signal line wire and the positive power supply rail to hold the default bus state high when idle.

79. Chip Select (CS) / Slave Select (SS)

Definition: A dedicated control line wire used in an SPI bus architecture to actively wake up and select a specific target peripheral chip to speak to.

80. Parity Bit

Definition: A simple, high-level error-checking bit appended to a data byte block to verify if the total count of '1' bits inside the message frame is even or odd.

Topic 9: Convolution & System Impulse Response

81. Impulse Response ($h[n]$)

Definition: The exact output sequence produced by a discrete-time digital signal system when its input is subjected to a single localized unit impulse signal.

Example: Mapping the brief decay sound print of a recording room by firing a sharp blank audio pistol crack near a microphone.

Analogy: Striking a large metal bell once with a hammer. The sound ring and vibration trail that fills the air after the strike is the bell's impulse response.

82. Convolution Sum

Definition: The core mathematical operation ($y[n] = x[n] * h[n]$) that calculates a system's output by flipping, shifting, and multiplying an input signal by the impulse response.

Example: Processing an electric guitar track inside a digital signal processor pedal to add an authentic vintage amplifier distortion warmth.

83. Unit Impulse Function

Definition: A fundamental discrete-time signal sequence whose value is exactly equal to 1 at sample index $n = 0$, and entirely equal to 0 at all other index points.

84. Linear System

Definition: A system that strictly satisfies both the properties of scaling (homogeneity) and addition (superposition), ensuring predictable signal outputs.

85. Time-Invariant System

Definition: A system whose internal processing characteristics do not alter or drift over chronological time; delaying the input delays the output identically.

Example: A digital voice filter software module that outputs the exact same pitch shift modification whether you speak into it today or next month.

86. Causality

Definition: A system property where the current output depends exclusively on current and historical past inputs, never relying on future untravelled signal data.

Example: A real-time hearing aid filter circuit processing sound waves as they hit the mic, incapable of predicting the next syllable ahead of time.

Analogy: Real life. You can make decisions based on what happened yesterday or what is happening right now, but you cannot change your steps based on tomorrow's news.

87. Stability (BIBO in DSP)

Definition: The structural filter condition where every bounded input sequence produces a strictly bounded output sequence that does not grow to infinity.

88. Z-Transform

Definition: A mathematical transform that converts discrete-time domain signal sequences into a complex frequency z-domain algebraic representation.

89. Transfer Function ($H(z)$)

Definition: The z-domain algebraic ratio of a system's output signal to its input signal, obtained by taking the Z-transform of its impulse response.

90. Frequency Response Function

Definition: The mathematical function that describes how a digital system or filter will scale the magnitude and shift the phase of incoming sinusoidal waves.

Topic 10: Low-Power Optimization & Watchdog Timers

91. Sleep Mode

Definition: A low-power microcontroller operational state where the CPU core stops executing code instructions and shuts down its main clock to conserve battery.

Example: Forcing a fitness tracking wristband to go dark and entering a low-draw state when the user is sitting perfectly still.

Analogy: Napping. You shut your eyes and rest to save your physical energy, but your ears stay open enough to wake up if someone knocks on the door.

92. Deep Sleep Mode

Definition: An ultra-low power state where almost all internal clocks, high-speed RAM spaces, and peripherals are powered down fully, leaving only bare wake-up pins alive.

Example: Putting an agricultural field soil moisture sensor probe into low-draw isolation for weeks between active water readings.

93. Watchdog Kick / Feed

Definition: The software operation of resetting a watchdog timer's internal countdown register back to its maximum value, preventing an accidental system reset.

Example: Placing a line of code like `WDT_Refresh();` at the very end of a master cyclic software system loop.

Analogy: A security guard punching a validation timecard machine every hour on the hour to prove to the main office that they are awake and alert.

94. Windowed Watchdog Timer (WWDT)

Definition: An advanced watchdog variant that triggers a hardware reset if the code attempts to refresh it either too late OR too early within a tight timing window.

Example: Protecting a critical automotive steer-by-wire controller loop from executing software routine errors that loop out of control too fast.

95. Brown-Out Reset (BOR)

Definition: An internal safety supervisor circuit that forces a clean system reset if the microcontroller's supply voltage falls below a critical operational threshold.

Example: Safely shutting down a smart locker control lock module when its AA batteries fade out to prevent the lock latch from freezing midway.

Analogy: An automated factory line circuit breaker that instantly trips and shuts down heavy machines if the municipal power grid voltage sags or brownouts.

96. Power-On Reset (POR)

Definition: A hardware initialization circuit that generates a clean reset pulse to clear registers and start code execution from line 1 when power is first turned on.

97. Prescaler

Definition: A hardware division configuration engine used to step down a high-frequency system master clock to run peripheral timers at slower, power-efficient speeds.

98. Clock Gating

Definition: A low-power design optimization technique that physically cuts off the clock signal line to inactive hardware peripherals, eliminating unnecessary switching power losses.

99. Dynamic Voltage and Frequency Scaling (DVFS)

Definition: A power management technique where the operational voltage and clock frequency of a processor are actively adjusted at runtime based on the real-time workload.

100. Wake-Up Source

Definition: A designated hardware trigger event (like an external GPIO pin edge, an RTC alarm, or a serial message character) that forces a microcontroller out of sleep.